



Brush Cover

Brush cover for self-service washing systems

The brush cover is particularly gentle to the paint due to its high-quality microfibre and protects the surface from dirt particles due to a sewn-in mesh. A cord with elastic allows it to be securely attached to self-service washing brushes. The brush cover is both water and foam permeable and can be transported in the water-repellent protective pouch after use. Weight in g/m²: 640; Size: 30 x 15 cm

page 1 of 1

Areas of use

Brushing in self-service washing systems

Recommendations for use

Pull the brush cover over the washing brush and secure it with the cord. After use, transport it in the water-repellent protective pouch, then wash and dry.

Container

Container	Item no.
1 pce	9998169

Warnings

Do not store the brush cover in the protective pouch when wet. Transport upright in the protective pouch. Hand wash up to 30 °C. Not suitable for tumble dryer. Do not iron. Do not bleach.

Notice

This product information can advise you only without obligation. Liability on our part can not be derived. Please check whether the product is suitable for your application. We will be pleased to assist you.